

# NePort™ Series User Manual



Conextop Technologies Co., Ltd.

All rights reserved

## Disclaimer

Copyright ©2003

Conextop, Inc.

All rights reserved.

Conextop, NePort, with its patent-pending technology, and neChip are trademarks of Conextop. All other trademarks are the property of their respective owners.

## Contacts

### **Conextop Ltd.**

Room 608, 6/F, Electric Building,  
High-tech Park, Nanshan,  
Shenzhen, China  
Phone: 86-755-26505615  
Fax: 86-755-26505565

### **Technical Support**

Online: [www.conextop.com/aboutus/contactus.htm](http://www.conextop.com/aboutus/contactus.htm)

### **Sales Offices**

For a current list of our domestic and international sales offices, go to the Conextop web site at [www.conextop.com](http://www.conextop.com)

## Related Documentation

Manual	Description
<b>CONEXTOP NEPORT User Manual</b>	The manual provides a description of management functions of NEPORT series products.
CONEXTOP NEPORT AT Commands	The manual provides a description of all the AT commands of NEPORT series product.

## Content

Introduce the functions and configuration to readers.

### readers

- NEPORT product engineers
- Users who are familiar with network

## Symbols



Caution, means reader be careful. Improper operation may cause data loss or damage to equipment.



Inhibition, means you must to do that.



Note, means a complementary description.

## Abbreviation

Abbreviation	Description
IP	Internet protocol
TCP	Transmission Control Protocol
UDP	User Datagram Protocol
NTP	Network time protocol
DNS	Domain Name System
SMTP	Simple mail transfer protocol
UART	
DHCP	Dynamic Host Configuration Protocol
BOOTP	BOOTstrap Protocol

## Table of contents

Chapter 1	Introduction.....	1-1
1.1	System Overview .....	1-1
1.2	Features and Specifications.....	1-2
1.2.1	Product Features.....	1-2
1.2.2	Product Specifications.....	1-2
1.3	Package Checklist .....	1-3
Chapter 2	Getting Started .....	2-1
2.1	Hardware connection and install.....	2-1
2.2	User Interface.....	2-1
2.2.1	Local configuration via serial port .....	2-1
2.2.2	Remote configuration via network.....	2-3
Chapter 3	Parameters.....	3-1
3.1	Basic Settings.....	3-1
3.2	Network.....	3-2
3.2.1	Automatic IP address configuration .....	3-2
3.2.2	Static IP address configuration.....	3-2
3.2.3	Ethernet configuration.....	3-3
3.2.4	Network Type.....	3-3
3.3	PPPoE .....	3-4
3.3.1	PPPoE .....	3-4
3.3.2	PPPoE Status.....	3-5
3.4	PPP.....	3-5
3.4.1	PPP .....	3-5
3.4.2	PPP Status .....	3-6
3.5	GPRS.....	3-6
3.5.1	MSC Settings .....	3-6
3.5.2	PPP .....	3-7
3.5.3	PPP Status .....	3-8
3.6	Server Settings .....	3-8
3.7	Hostlist .....	3-9
3.7.1	Retry Settings.....	3-9
3.7.2	Host Information.....	3-9
3.8	Serial Settings .....	3-10
3.8.1	Enable Serial Port.....	3-10
3.8.2	Port Settings .....	3-10
3.8.3	Pack Control.....	3-11
3.9	Connection .....	3-11
3.9.1	Connection Protocol.....	3-11
3.9.2	UDP.....	3-12
3.9.3	TCP .....	3-12
3.10	Email Settings .....	3-15
3.10.1	Configure Server .....	3-15

3.10.2 Recipients.....	3-16
3.11 Trigger Settings.....	3-16
3.11.1 Conditions.....	3-16
3.11.2 Message Properties.....	3-17
3.12 Input Trigger Settings.....	3-17
3.12.1 Serial Trigger.....	3-17
3.12.2 Message Properties.....	3-18
3.13 SNMP.....	3-18
3.14 Password Setting.....	3-19
3.14.1 Change Password.....	3-19
3.15 Power manage.....	3-19
Chapter 4 Web Configuration.....	4-1
4.1 Basic Settings.....	4-1
4.2 Network.....	4-2
4.3 PPPoE.....	4-3
4.4 PPP.....	4-3
4.5 GPRS.....	4-4
4.6 Server Settings.....	4-5
4.7 Serial Channel.....	4-6
4.7.1 Hostlist.....	4-6
4.7.2 Serial Settings.....	4-7
4.7.3 Connection.....	4-8
4.8 Email Settings.....	4-10
4.9 Trigger Settings.....	4-11
4.10 Input Trigger Settings.....	4-12
4.11 SNMP Settings.....	4-13
4.12 Password Setting.....	4-13
4.13 Power manage.....	4-14
4.14 Logout.....	4-14
Chapter 5 TELNET Configuration.....	5-1
5.1 Basic Settings.....	5-1
5.2 Network.....	5-1
5.2.1 Static IP address configuration.....	5-2
5.2.2 Dynamic IP address configuration.....	5-2
5.2.3 Netcard setting.....	5-2
5.2.4 Network type.....	5-3
5.3 PPPoE.....	5-3
5.4 PPP.....	5-4
5.5 GPRS.....	5-4
5.6 Server Settings.....	5-5
5.7 Channel settings.....	5-5
5.7.1 Hostlist.....	5-6
5.7.2 Serial Settings.....	5-7
5.7.3 Connection.....	5-7

5.8	Email Settings .....	5-8
5.8.1	Email Settings .....	5-9
5.8.2	Trigger Settings .....	5-9
5.8.3	Input Trigger Settings.....	5-10
5.9	SNMP Settings .....	5-10
5.10	User Manage .....	5-11
5.11	Password Setting .....	5-12
5.12	Load factory default .....	5-12
5.13	Save and Reboot.....	5-12
5.14	View Settings .....	5-13
Chapter 6	AT Command .....	6-1
6.1	AT commands for parameters setting .....	6-1
6.1.1	Basic Settings .....	6-1
6.1.2	Network.....	6-1
6.1.3	PPPoE .....	6-1
6.1.4	PPP .....	6-2
6.1.5	GPRS.....	6-2
6.1.6	Server Settings .....	6-2
6.1.7	Host list .....	6-2
6.1.8	Serial Settings .....	6-2
6.1.9	Connection .....	6-3
6.1.10	Email Settings .....	6-3
6.1.11	Trigger Settings .....	6-3
6.1.12	Input Trigger Settings.....	6-3
6.1.13	SNMP.....	6-4
6.1.14	Password Setting .....	6-4
6.1.15	Special command .....	6-4
6.2	FTP AT command.....	6-4
6.2.1	Local and device .....	6-5
6.2.2	Local and FTP server .....	6-5
6.2.3	Device and FTP server .....	6-5
6.2.4	Read file procedure .....	6-5
6.2.5	Write to file procedure .....	6-6
Chapter 7	DeviceManagement .....	7-1
7.1	Functions.....	7-1
7.1.1	Menu Items .....	7-1
7.1.2	Shortcuts Field .....	7-3
7.1.3	Devices List View .....	7-3
7.2	Configuring Devices .....	7-4
7.2.1	Login.....	7-4
7.2.2	Configure .....	7-4

# Chapter 1 Introduction

## 1.1 System Overview

Conextop Technologies target at providing the most reliable and security M2M solution for the worldwide customers, and NePort is the most compact serial-IP module released in 2002, which has embedded all in a standard RJ45 connector, Neport is powered by our network processor SoC(Nechip), which includes a 10/100 MAC/PHY and 256 KB of SRAM on chip. It features a built-in web server for communications with a device via a standard Internet browser. Web capability can be used for remote configuration, real-time monitoring or troubleshooting. Neport has 512 KB of on-chip Flash for web pages and software upgrades. It acts as a dedicated co-processor that optimizes network activities permitting the host microprocessor to function at maximum efficiency.

NePort series of Industrial Device Servers are a robust, feature-rich, high reliability, high-performance and cost effective way to network-enable equipment in an industrial automation environment. In accordance with the needs of users, NEPORT series can provide one or more serial ports, provide a cost-effective program for users to connect the RS232/RS422/RS485 serial equipment to network.

NePort series integrates internal TCP / IP protocol stack to provide a complete network access and data transmission functions. And can provide a wide range of access means, including ETHERNET, PPP, PPPoE, GPRS, and users can choose one or more access methods according to actual demand.

NePort Series provides users with a wealth of features and applications. in order to facilitate the using, provides convenient configuration including serial, HTTP, TELNET and other, the user can choose different ways to configure. And in order to facilitate the management of equipment, NEPORT Series also provides windows applications to manage multiple devices on the network through its centralized management and configuration functions.

In order to compatible with traditional serial applications, NePort Series also provides users with the virtual serial port, so users do not need to modify existing applications to control the physical serial port through network.

## 1.2 Features and Specifications

### 1.2.1 Product Features

The NEPORT Series products have the following features:

- Easy to connect to the Internet network
- Serial transmission speed up to 921600bps
- Supports 10/100 Mbps Ethernet—auto-detectable
- Supports access to Internet network by PPP
- Supports access to Internet network by PPPoE
- Supports access to Internet network by GPRS
- Supports RS-232/422/485 interface
- Supports UDP Unicast/Multicast、TCP SERVER、TCP CLIENT working mode
- Supports a wide range of configuration, including WEB, TELNET, and serial port
- Supports virtual serial ports on Windows
- Supports SNMP protocol and MIBII for network management
- Supports SMTP protocol for email alerting
- Supports TFTP and FTP protocol for web and firmware upgrading

### 1.2.2 Product Specifications

#### LAN

- Type: 10M/100Mbps
- Interface: RJ45

#### Serial Interface

- protocols: RS232/RS422/RS485
- Baud: 110bps-460800bps
- Data bits: 5, 6, 7, 8
- Stop bits: 1、1.5、2
- Parity: None, Even, Odd, Space, Mark
- Flow control: none, software, hardware

#### GSM/GPRS

- Dual-Band GSM 900/1800 MHz, compliant to GSM phase 2/2+
- Output power: Class 4 (2W)/(EGSM900), Class 1(1W)/(GSM1800)
- GPRS multi-slot class 10
- Mobile station class B

#### Protocols

- ICMP、IP、TCP、UDP、DHCP、BOOTP、TELNET
- DNS、SNMP、HTTP、SMTP、SNTP、ARP



- PPP、PAP、CHAP、LCP、IPCP
- PPPOE、FTP、TFTP
- SSH、SSL、TLS、HTTPS、SMTPS

#### File System

- FAT12/16/32

#### Others

- dimension:
- power input: 3.3VDC, +/-5%;4.2VDC,+/-5%
- power consumption: 250mA
- Operation temperature: 0°C to +70°C (32°F to 158°F), 5% to 95% RH
- Store temperature: -20°C to +85°C (-4°F to 185°F), 5% to 95% RH

## 1.3 Package Checklist

NEPORT serial device server	1
User manual	1 (CD)
Serial Cable	1
Power supply	1

## Chapter 2 Getting Started

### 2.1 Hardware connection and install

Please refer to <<NePort Hardware Description>>

### 2.2 User Interface

The device's configuration is stored in nonvolatile memory and is retained without power. You can change the configuration at any time. The unit performs a reset after you change and store the configuration.

In order to improve the flexibility and convenience, NEPORT series of products provides a wide range of configuration tools for the user to choose, including: serial login configuration, WEB configuration, TELNET configuration, device manager configuration.

#### 2.2.1 Local configuration via serial port

Connect serial port to NEPORT to build the local environment:

- 1, connect the computer serial port with NEPORT through a standard serial cable.
- 2, open the terminal simulation program in the computer, such as HyperTerm (HyperTerminal) on Windows system or Minicom on Linux system, to establish a new connection, select the actual serial port to use, and set the serial parameters as follows(take HyperTerm as a example):



Figure 2-1 new connection of COM



Figure 2-2 select port




Figure 2-3 port settings




Figure 2-4 terminal type settings


3、 When the devices rebooted, input in the terminal with 3 "+" (in intervals of not more than 1s), can enter the device configuration mode.

## 2.2.2 Remote configuration via network

### 2.2.2.1 Configure IP address of local PC

To configure TCP/IP manually:


- 1、 In Control Panel, open Network and Dial-up Connections .
- 2、 Right-click the local area connection you want to modify.
- 3、 Select Properties .
- 4、 In the General dialog box, select Internet Protocol (TCP/IP) .
- 5、 Click Properties .



- 6、 In the General dialog box, select the Use the following IP address option.
- 7、 Type the IP address, subnet mask, and default gateway in the respective boxes.  
The network administrator must provide these values for individual users, based on the IP addressing plan for your site.

The value in the IP Address box identifies the IP address for the interface.


The value in the Subnet Mask box is used to identify the network ID for the selected network adapter.



- 8、Click OK to save the IP addressing information.
- 9、Click OK to save the connection properties.

To configure a multihomed system using a single network adapter:

- 1、In Control Panel, double-click Network and Dial-up Connections .
- 2、Right-click the local area connection you want to modify, and then select Properties .
- 3、Add TCP/IP configuration information for the first IP address, as described in Configure IP Address Manually.
- 4、Click Advanced .
- 5、Click Add to enter the IP address and subnet mask for each additional subnet.



### 2.2.2.2 Configuration via WEB

With integrated WEB server, users can easily access to the NEPORT Series product.

- 1、Open your browser and type the IP address in address input box and press Enter;
- 2、when connected successful, You may be prompted for your user name and password. Be sure to enter your new password.
- 3、If the user name and password is correct, the main page of device will be opened. The left part of main page is the index column; the right part is the overview information about the system.




Figure 2-5 HTTP main menu

### 2.2.2.3 Configuration via TELNET

With integrated TELNET server, NEPORT series product supports multi-user login at the same time, and supports a wide range of TELNET client, you can use command line tools as TELNET client under the Windows and Linux. In the following we use Windows as an example to show the detailed operation of TELNET command line tools.

- 1、Open "Run" under the "Start" menu, type "cmd" to start command-line tool .




Figure 2-6 run the cmd tool

- 2、Under the command line type "telnet dd.dd.dd.dd" and enter, in which "dd.dd.dd.dd" refers to the device address to login, the device address is "192.168.0.251" below.




Figure 2-7 TELNET connect to server

3、After that, please according to the screen prompt to enter a user name and password to complete the login.



Figure 2-8 TELNET login page

4、When authenticate success, the main menu will show as follows:




Figure 2-9 TELNET main menu

## 2.2.2.4 Configuration via Device manager

NEPORT series products support PC client management software “DeviceManagement” to manage and configure devices.

1, according to the products installation files of “DeviceManagement” that found in the accompanying software package and begin software installation.



2, after the success of the software installation, there is a shortcut will be generated on the desktop, through the shortcut or through the "Start" menu to find DeviceManagement menu items, you can open DeviceManagement software interface as follows:




Figure 2-10 Device Manager

## Chapter 3 Parameters

NEPORT series products with rich functions in actual use, the user needs to configure it as needed, select the required function, cancel the function does not required. NEPORT Series products have a variety of means of configuration, In order to know the content of configuration, in the following chapter, the parameters of the equipment will be introduced one by one.



Note:

Configuration tool Introduced in the follow-up such as WEB, TELNET, have the same sub-sections of this chapter.

---

### 3.1 Basic Settings

parameter	contents
Server Name	The name of device server Option value: any string length less than 14 bytes. Default value: NULL Notes: it will not change when load factory setting.
Time	Set the current time of device: Time Zone: User selectable time zone. Local Time: System time. Time Server: Server name used to synchronize the time.
Web Console	Enable or disable web service.
Telnet Console	Enable or disable telnet service.
Terminal Type	Some of the old terminal may be required before the connection is established in the terminal type of transmission. You may need to refer to the documentation to determine the appropriate type. In most applications of modern terminals, this is not a necessity, can not serve any purpose. Suggested default value: VT100.

Table 3-1 basic setting parameters

**Caution:**

As the two remote access methods, if the HTTP and TELNET are disabled, the device can not be accessed by network.

---

## 3.2 Network

### 3.2.1 Automatic IP address configuration

parameter	contents
BOOTP	Whether or not to allow BOOTP to obtain IP address.
DHCP	Whether or not to allow DHCP to obtain IP address.
AutoIP	Whether or not to allow AutoIP to obtain IP address.
DHCP Host Name	DHCP server host name.

Table 3-2 Automatic IP address configuration

**Note:**

DHCP protocol is developed based on the BOOTP protocol and is compatible with BOOTP protocol, if is not clear, the best choice is DHCP, because BOOTP protocol protocol can not be compatible with DHCP.

---

### 3.2.2 Static IP address configuration

parameter	contents
IP Address	Static ip address of device.
Subnet	Ip address network mask
Default Gateway	Gateway of network.
Preferred DNS server	The 1 <sup>st</sup> DNS server to use when query.
Alternate DNS server	The second DNS server to use when query.

Table 3-3 static IP address



Inhibition:

If you choose to use manually configure IP addresses, IP address can not the same as the others in the same network, otherwise it will leading to unpredictable consequences.

### 3.2.3 Ethernet configuration

parameter	contents
Auto Negotiate	Auto-negotiation is selected, the device will auto-negotiate with the network node of the network; uncheck it will using the designated mode. Option values: Enable/Disable Default value: Enable
Speed	Netcard working speed. Option values(bps): 10M/100M. Default value: 10M
Duplex	Netcard working mode. Option values: Full or Half. Default value: Full
MAC Address	Mac address of netcard. Option value: valid mac address in “xx.xx.xx.xx.xx.xx” format. Default value: None.

Table 3-4 ethernet configuration



Inhibition:

In the LAN, MAC address are used to distinguish between the various devices or PC, MAC address of device can not be the same with any other device or PC machine in the network.

### 3.2.4 Network Type

parameter	contents
Ethernet	Whether or not to enable ethernet
PPP	Whether or not to enable PPP dialup network
PPPoE	Whether or not to enable PPPoE dial-up network
GPRS	Whether or not to enable GPRS

Table 3-5 network type

## 3.3 PPPoE

### 3.3.1 PPPoE

parameter	contents
User Name	User name of dial-up account Option value: any string of length less than 31 bytes. Default value: "admin"
Password	Password of dial-up account. Option value: any string of length less than 21 bytes. Default value: "admin"
Work Mode	Work mode of dial-up. Option value: Disable: Disable the PPPoE dial-up function, the device can not access network through PPPoE. Auto Dial: In such mode, the device will try to keep the dial-up connection. Once the connection is disconnect, it will try to connect again until connect success. Dial on Demand: When the device have to send data to network, but dial-up connection is disconnected, it will dial up to connect. Should use in cooperate with Idle Time. Adaptive: The device will use PPPoE dial-up connection or LAN to transmit data automatically. Default value: Disable.
Max Redial Times	Times of redial when failed to login, Only valid in Dial on Demand mode. Option value: 0-255 Default value: 0
Redial Interval	Interval time of redial when failed to login. Option value: 0-255 Default value: 0
Idle Time	When the dial-up connection is idle after idle time, it will be compelled to disconnect. Option value(secs): 0-65535 Default value: 0

Table 3-6 PPPoE dial-up settings

### 3.3.2 PPPoE Status

PPPoE status parameters are read-only, to display status of PPPoE dial-up connection.

parameter	contents
Link Status	Status of dial-up connection. Option value: deactive/linking/active. Default value: deactive.
PPPoE IP	IP address of dial-up connection.
PPPoE Gateway	Gateway of dial-up connection.
PPPoE DNS1	Preferred DNS address of dial-up connection.
PPPoE DNS2	Alternative DNS address of dial-up connection.

Table 3-7 PPPoE state

## 3.4 PPP

### 3.4.1 PPP

parameter	contents
User Name	User name of dial-up account Option value: any string of length less than 31 bytes. Default value: "admin"
Password	Password of dial-up account. Option value: any string of length less than 21 bytes. Default value: "admin"
Work Mode	Work mode of dial-up. Option value: Disable: Disable the PPP dial-up function, the device can not access network through PPP. Auto Dial: In such mode, the device will try to keep the dial-up connection. Once the connection is disconnect, it will try to connect again until connect success. Dial on Demand: When the device has to send data to network, but dial-up connection is disconnected, it will dial up to connect. Should use in cooperate with Idle Time. Adaptive: The device will use PPP dial-up connection or LAN to transmit data automatically. Default value: Disable.

Max Redial Times	Times of redial when failed to login, Only valid in Dial on Demand mode. Option value: 0-255 Default value: 0
Redial Interval	Interval time of redial when failed to login. Option value: 0-255 Default value: 0
Idle Time	When the dial-up connection is idle after idle time, it will be compelled to disconnect. Option value(secs): 0-65535 Default value: 0
COM	Which serial port is used for dial-up. Option value: vary according to firmware. Default value: vary according to firmware.

Table 3-8 PPP dial-up

### 3.4.2 PPP Status

PPPoE status parameters are read-only, to display status of PPPoE dial-up connection.

parameter	contents
Link Status	Status of dial-up connection. Option value: deactive/linking/active. Default value: deactive.
PPP IP	IP address of dial-up connection.
PPP Gateway	Gateway of dial-up connection.
PPP DNS1	Preferred DNS address of dial-up connection.
PPP DNS2	Alternative DNS address of dial-up connection.

Table 3-9 PPP status

## 3.5 GPRS

### 3.5.1 MSC Settings

parameter	contents
Access Point Name	The name used to identify a general packet radio service (GPRS) bearer service in the GSM mobile network. The APN defines the type of service that is provided in the packet data connection. Option values: Any string provided by mobile operator. Default value: CMNET
Service Code	Dial string. Option values: any string provided by mobile operator.

	Default value: *99***1#
SIM/UIM PIN	SIM PIN1 Option values: any string provided by mobile operator. Default value: NULL

Table 3-10 GPRS mobile services center

### 3.5.2 PPP

parameter	contents
User Name	User name of dial-up account Option value: any string of length less than 31 bytes. Default value: "admin"
Password	Password of dial-up account. Option value: any string of length less than 21 bytes. Default value: "admin"
Work Mode	Work mode of dial-up. Option value: Disable: disable the PPP dial-up function, the device can not access network through PPP. Auto Dial: In such mode, the device will try to keep the dial-up connection. Once the connection is disconnect, it will try to connect again until connect success. Dial on Demand: When the device has to send data to network, but dial-up connection is disconnected, it will dial up to connect. Should use in cooperate with Idle Time. Adaptive: The device will use PPP dial-up connection or LAN to transmit data automatically. Default value: Disable.
Max Redial Times	Times of redial when failed to login, Only valid in Dial on Demand mode. Option value: 0-255 Default value: 0
Redial Interval	Interval time of redial when failed to login. Option value: 0-255 Default value: 0
Idle Time	When the dial-up connection is idle after idle time, it will be compelled to disconnect. Option value(secs): 0-65535 Default value: 0



COM	Which serial port is used for dial-up. Option value: vary according to firmware. Default value: vary according to firmware.
-----	---

Table 3-11 GPRS PPP dial-up

### 3.5.3 PPP Status

PPPoE status parameters are read-only, to display status of PPPoE dial-up connection.

parameter	contents
Link Status	Status of dial-up connection. Option value: deactive/linking/active. Default value: deactive.
PPP IP	IP address of dial-up connection.
PPP Gateway	Gateway of dial-up connection.
PPP DNS1	Preferred DNS address of dial-up connection.
PPP DNS2	Alternative DNS address of dial-up connection.

Table 3-12 GPRS PPP status

## 3.6 Server Settings

parameter	contents
ARP cache Timeout(secs)	Timeout time of ARP entry. When timeout, the system will renew the ARP entry, if fail, the entry will be deleted. Alternative values(secs): 0-255. Default value: 255
CPU Performance Mode	CPU running mode. Alternative values: High/Normal. Default value: Normal. Note: if in high speed mode, it will cost more power and more faster.
HTTP Server Port	Web server's service port. Alternative values: 1-65535. Default value: 80
MTU Size	The size of maximum transmit unit in bytes. Can not be modified.

Table 3-13 server settings

## 3.7 Hostlist

### 3.7.1 Retry Settings

parameter	contents
Retry Counter	The re-connect times when the device connects the remote host fails. When the number of retries reached but the device still unable to connect to the remote host, it will select other address in the host list to connect; the above process will be repeated until a successful connection to a host in the list of hosts. It's value must be within 0 to 255, 0 means no retry.
Retry Timeout	If the device connect the remote host fails, the timeout to re-trying to connect. Retry timeout when still can not connect to reach the remote host, the module will select the host list of other addresses to connect to remote host; the above process will be repeated until a successful connection to a host in the list of hosts.

Table 3-14 retry settings



Note:

When reach retry counter or retry timeout, the device will give up retry the same host and try another host.

### 3.7.2 Host Information

parameter	contents
Host Address	Host's IP address.
Port	Host's port number.
Backup link	Whether or not to support a backup link. If enabled, the device will establish 2 connections and transmit data on both. Otherwise, only one connection can be established in a time.

Table 3-15 remote host information

## 3.8 Serial Settings

### 3.8.1 Enable Serial Port

parameter	contents
Enable Serial Port	Whether or not enable serial port Option value: Enable/Disable Default value: Enable

Table 3-16 enable serial port



#### Caution:

When the serial port is disabled, then it can not be used to send and receive data, also can not use the AT commands and serial login capabilities via it.

### 3.8.2 Port Settings

parameter	contents
Protocol	Protocol used in serial port communication. Option values: RS232/RS422/RS485. Default value: RS232.
FIFO	Serial port hardware FIFO length. Option values: 4, 8, 16. Default value: 8
Flow Control	Option values: None/Software/Hardware. Default value: None.
Baud Rate	Serial port baud rate. Option values(bps): 110/134/150/300/600/1200/1800/2400/4800/7200/9600/14400/19200/38400/57600/115200/230400/460800/921600 Default value: 9600
Data Bits	Data bits used in serial communication. Option values(bit):8/7/6/5 Default value:9
Parity	Option values: NONE/ODD/EVEN/MARK/SPACE. Default value: NONE.
Stop bits	Option values (bit): 0/1.5/2. Default value: 0.

Table 3-17 serial port settings

**Caution:**

Configuration at both ends of the serial line must be the same.

### 3.8.3 Pack Control

parameter	contents
Enable Packing	Whether or not to enable packing function. How to packing serial data stream is dependant on the following parameters. Option value: Enable/Disable Default value: Disable
Idle Gap Time	Maximum time for inactivity. If there is any data on serial port's receive buffer, they will be packed and sent to network. Option value(ms): 12/11/10 Default value: 12
Match 2 Byte Sequence	If enabled, used the two match bytes to indicate the beginning and end of a series of data to be sent as one group. Otherwise, used the first match byte to indicate the end of a series of data to be sent as one group. Option value: Enable/Disable. Default value: Disable.
Send Frame Only	After the detection of the byte sequence, indicates whether to send the data frame or the entire buffer. Option value: YES/NO. Default value: YES
Match Byte	Used to indicate the beginning and the end of a series of data to be sent as one group. Option value(HEX): 0x00-0xFF Default value: 0x00

Table 3-18 serial packing settings

## 3.9 Connection

### 3.9.1 Connection Protocol

parameter	contents
Protocol	Network protocol Option values: TCP/UDP Default value: TCP

Table 3-19 connection protocol

## 3.9.2 UDP

### 3.9.2.1 Datagram Mode

parameter	contents
Datagram Type	Type of udp datagram. Option values: Uni: unicast type. Multi: multi-cast type. Default value: Uni.
Accept Incoming	Whether to accept UDP data from remote host. Option values: YES/NO. Default value: YES

Table 3-20 UDP datagram mode

### 3.9.2.2 Multi-Cast Configuration

parameter	contents
Local Port	Local port used to communicate with remote.
Remote Port	Remote host's port.
Net Segment	Remote host's multi-cast address.

Table 3-21 UDP multi-cast configuration

### 3.9.2.3 Uni-Cast Device Address Table

parameter	contents
Device Address	Remote host's uni-cast address.
Port	Remote host's port in uni-cast communication.
Local Port	Local port used in uni-cast communication.

Table 3-22 UDP uni-cast device address table

## 3.9.3 TCP

### 3.9.3.1 Connect Mode

parameter	contents
Worked As	Work mode of TCP.

	<p>Option values:</p> <p>Server: As a server and accept new connection of remote.</p> <p>Client: As a client, connect to remote host initiatively.</p> <p>Both:</p> <p>Default: Server.</p>
--	---

Table 3-23 TCP connection mode

### 3.9.3.2 Active Connection

parameter	contents
Active Connect	<p>When work as a client, when to connect to remote host.</p> <p>Option values:</p> <p>None: Disabled.</p> <p>With Any Character: when receive any character in serial port.</p> <p>With Start Character: when receive a specified character in serial port.</p> <p>Auto Start: auto start when system starts and tries to keep.</p> <p>Default value: None.</p>
Start Character	The specified character to trigger initiative connects. The character must in HEX format.

Table 3-24 TCP active connection

### 3.9.3.3 Connection Configuration

parameter	contents
Local Port	<p>When working as server, it is the listening port;</p> <p>When working as client, it is the local port of connection.</p> <p>Value range: 0-65535</p> <p>Default value:0</p>
Remote Port	The remote host's communication port.
Remote Host	The host name or IP address of remote.
Connect Response	<p>When a TCP connection is established, the device will send a character 'C' to serial port. When a TCP connection is disconnected, the device will send a character 'D' to serial port.</p> <p>Alternative values:</p> <p>None: disable.</p> <p>ACT: enable.</p> <p>Default value: None.</p>
Use Host list	<p>Whether or not to use host list table.</p> <p>Alternative values: YES/NO.</p> <p>Default value: NO.</p>

Table 3-25 TCP connection configuration

### 3.9.3.4 Disconnect Mode

parameter	contents
On DSR Drop	All TCP connection will be disconnect when serial's DSR pin 's voltage transfer from high to low. Alternative value: Enable/Disable. Default value: Disable. Note: Only work on modem port.
Hard Disconnect	The TCP connection will closes even if the remote site does not acknowledge the disconnect request. Option value: Enable/Disable. Default value: Disable.
Check EOT(Ctr-D)	Disconnect all connection when receive a character EOT(ctrl+D) on the serial port. Alternative value: Enable/Disable. Default value: Disable;
Inactivity Timeout	When the TCP connection is idle (without any data transmission) for a specified time, disconnect the connection automatically. If the specified time is 0, disable this function. Alternative values: 0-255. Default value: 255.

Table 3-26 TCP disconnect mode

### 3.9.3.5 Flush Input Buffer

parameter	contents
With Active Connect	Whether or not to clear the input buffer of serial port when the device initiative connect to the remote. Option value: Enable/Disable. Default value: Disable.
With Passive Connect	Whether or not to clear the input buffer of serial port when a remote host initiative connect to the device. Option value: Enable/Disable. Default value: Disable.
At Time of Disconnect	Whether or not to clear the input buffer of serial port when the connection of the device is disconnected. Option value: Enable/Disable. Default value: Disable.

Table 3-27 flush input buffer of serial port

### 3.9.3.6 Flush Output Buffer

parameter	contents
With Active Connect	Whether or not to clear the output buffer of serial port when the device initiative connect to the remote. Option value: Enable/Disable. Default value: Disable.
With Passive Connect	Whether or not to clear the output buffer of serial port when a remote host initiative connect to the device. Option value: Enable/Disable. Default value: Disable.
At Time of Disconnect	Whether or not to clear the output buffer of serial port when the connection of the device is disconnected. Option value: Enable/Disable. Default value: Disable.

Table 3-28 flush output buffer of serial port

## 3.10 Email Settings

### 3.10.1 Configure Server

parameter	contents
SMTP Domain Name	Domain name or IP address of SMTP server. Option values: any domain name string length less than 31bytes. Default value: NULL
SMTP Port	Port of SMTP server. Option values: 1-65535 Default value: 25
Email Address	User email address used to send mail. Option values: any email address string length less than 31 bytes. Default value: NULL
Username	Name of user account. Option values: any string length less than 31 bytes. Default value: NULL
Password	Password of user account. Option values: any string length less than 31 bytes. Default value: NULL

Table 3-29 email server settings



### 3.10.2 Recipients

parameter	contents
Recipient 1 Email	Enter the email address designated to receive email notifications. Option values: any email address string length less than 31 bytes. Default value: NULL
Recipient 2 Email	Enter the email address designated to receive email notifications. Option values: any email address string length less than 31 bytes. Default value: NULL
Recipient 3 Email	Enter the email address designated to receive email notifications. Option values: any email address string length less than 31 bytes. Default value: NULL

Table 3-30 email recipients

## 3.11 Trigger Settings

### 3.11.1 Conditions

parameter	contents
Cold start	Whether or not to send a email when the device is cold start (hardware reset). Option value: Mail On/Mail Off. Default value: Mail Off.
Warm start	Whether or not to send a email when the device is warm start (software reset). Option value: Mail On/Mail Off. Default value: Mail Off.
Login auth failure	Whether or not to send a email when there is a login authenticate failure. Option value: Mail On/Mail Off. Default value: Mail Off.
IP address changed	Whether or not to send a email when the device's IP address is changed. Option value: Mail On/Mail Off. Default value: Mail Off.
Password changed	Whether or not to send a email when the device's login

	password is changed. Option value: Mail On/Mail Off. Default value: Mail Off.
DCD Changed	Whether or not to send a email when the DCD state of modem port is changed. Option value: Mail On/Mail Off. Default value: Mail Off.
DSR Changed	Whether or not to send a email when the DSR state of modem port is changed. Option value: Mail On/Mail Off. Default value: Mail Off.

Table 3-31 normal email trigger event

### 3.11.2 Message Properties

parameter	contents
Subject	Subject of mail to send. Option values: any string length less than 31 bytes. Default value: NULL
Priority	Mail priority. Option values: High/Low/Normal. Default value: Normal.
Min.Notification Interval	The minimum time allowed between individual triggers. If a trigger event occurs within the minimum interval since the last trigger, it is ignored. Option value(secs): 0-255 Default value: 0

Table 3-32 normal email trigger message properties

## 3.12 Input Trigger Settings

### 3.12.1 Serial Trigger

parameter	contents
Enable Serial Input Trigger	Whether or not to enable email trigger of serial port input. Option value: Enable/Disable. Default value: Disable.
Channel	The channel number used as a serial input trigger. Option value: according to different version of product. Default value: according to different version of product.
Data Size	Continuous characters number used to trigger email. Option value: Two Bytes/Three Bytes.

	Default value: Two Bytes.
Match Data	Character used to trigger email. Option value(in hex): 0x00-0xFF Default value: 0x00

Table 3-33 serial input trigger

### 3.12.2 Message Properties

parameter	contents
Subject	Subject of mail triggered by serial input data. Option value: any string length less than 31 bytes. Default value: NULL
Priority	Priority of mail triggered by serial input data. Option value: High/Normal/Low. Default value: Normal.
Min.Notification Interval	The minimum time allowed between individual serial input triggers. If a trigger event occurs within the minimum interval since the last trigger, it is ignored. Option value(secs): 0-255 Default value:0

Table 3-34 serial input trigger message properties

## 3.13 SNMP

parameter	contents
Disable SNMP	Whether or not disable SNMP. Option value: YES/NO. Default value: YES.
Read Community	String used to read SNMP MIB variables. Option values: any string length less than 17bytes. Default value: public
Write Community	String used to write SNMP MIB variables. Option values: any string length less than 17bytes. Default value: private
Contact Name	Contact name of SNMP MIBII. Option values: any string length less than 31bytes. Default value: NULL
Location	Location of SNMP MIBII. Option values: any string length less than 17bytes. Default value: Shenzhen
Notification Host	The host IP address of SNMP TRAP message. Option value: any string in IP address format.

	Default value: 0.0.0.0
--	------------------------

Table 3-35 SNMP

## 3.14 Password Setting

### 3.14.1 Change Password

parameter	contents
Username	User name for web login. Option values: any string length less than 11 bytes. Default value: admin
Old Password	Current password for web login, only need when change password.. Option values: any string length less than 11 bytes. Default value: admin
New Password	New password for web login when change password. Option values: any string length less than 11 bytes. Default value: admin
Retry Password	Confirm new password for web login when change password. Option values: any string length less than 11 bytes. Default value: admin

Table 3-36 change password



Caution:

If the password is lost, then press the default button to restore the factory value of parameters, use the default user name and password "admin" on the login again.

## 3.15 Power manage

parameter	contents
Load defaults	Restore factory settings.
Load defaults and reboot	Restore factory settings and reboot.
Reboot	Just reboot the device.
Save and reboot	Save the parameters and reboot.

Table 3-37 power manage

## Chapter 4 Web Configuration

Through a Web browser to configure the device is the most intuitive and convenient way. Here recommend the use of the mainstream browser, such as IE or FireFox for a visit.

In the following sections about WEB configuration, if there is no special note, the user need clicks on the "Submit" button of the page to submit data, configuration only take effect after the restart.

Configuration of device have been carried out in accordance with the relevant portfolio, located in different sub-page, please click on the left column of the corresponding sub-index into the configuration menu, the specific configuration items will be explained in the following sections of this chapter, and provide a description page, click the "Help" button next to "submit" on the page to view.

One suggestion was that in the configuration of device, please first finish modify all the configuration, and then click "Apply Settings / Restart" to restart, to improve the efficiency.



Note:

Map page of this chapter are for reference only, there are may be small differences in the content and WEB page in actual products.

---

### 4.1 Basic Settings

In the main menu click on "Basic Settings" link, basic configuration page will show as follows:

#### Basic Settings

---




Figure 4-1 HTTP basic settings page

Please refer to section 3.1 to see the description of the parameters.

## 4.2 Network

In the main menu click on “Network” link, network configuration page will show as follows:

---

**IP Configuration**

☐ Automatically obtain IP address:  
BOOTP: ☐ Disable ☒ Enable  
DHCP: ☐ Disable ☒ Enable  
AutoIP: ☐ Disable ☒ Enable  
DHCP Host Name:

☒ Use the following IP configuration:  
IP Address:   
Subnet:   
Default Gateway:   
Preferred DNS server:   
Alternate DNS server:

---

**Ethernet Configuration**

☒ Auto Negotiate  
Speed: ☒ 10M ☒ 100M  
Duplex: ☐ Half ☒ Full  
MAC Address:

---

**Network Type**

☒ Ethernet ☐ PPP ☐ PPPoE ☐ GPRS

Figure 4-2 HTTP network settings page

There is three parts in this page for configuration: IP configuration, Ethernet Configuration, Network Type. Please refer to the description of the parameters in section 3.2, 3.2.3, 3.2.4.

## 4.3 PPPoE

In the main menu click on “PPPoE” link, PPPoE configuration page will show as follows:

### PPPoE Settings

---

PPPoE Configuration:	
User Name:	<input type="text" value="admin"/>
Password:	<input type="password" value="•••••"/>
Work Mode:	<input type="text" value="Disable"/> ▼
Max Redial Times:	<input type="text" value="5"/>
Redial Interval:	<input type="text" value="5"/>
Idle Time:	<input type="text" value="600"/>
PPPoE Status:	
Link Status:	Disconnected
PPPoE IP:	0.0.0.0
PPPoE Gateway:	0.0.0.0
PPPoE DNS1:	0.0.0.0
PPPoE DNS2:	0.0.0.0
<input type="button" value="Submit"/> <input type="button" value="help"/>	

Figure 4-3 HTTP PPPoE settings page

There is two parts in this page for configuration: PPPoE configuration, PPPoE status. Please refer to the description of the parameters in section3.3.1, 3.3.2.

## 4.4 PPP

In the main menu click on link “PPP”, PPP configuration page will show as follows:

## PPP Settings

---

**PPP Configuration:**

User Name:

admin

Password:

•••••

Work Mode:

Disable

▼

Max Redial Times:

5

Redial Interval:

5

Idle Time:

600

COM:

COM1

▼

**PPP Status:**

Link Status:	Disconnected
PPP IP:	0.0.0.0
PPP Gateway:	0.0.0.0
PPP DNS1:	0.0.0.0
PPP DNS2:	0.0.0.0

Submit

help

Figure 4-4 HTTP PPP settings page

There is two parts in this page for configuration: PPP configuration, PPP status. Please refer to the description of the parameters in section 3.4.1, 3.4.2.

## 4.5 GPRS

In the main menu click on link “GPRS”, GPRS configuration page will show as follows:



## GPRS Settings

---

<b>MSC Settings</b>	
Service Code:	<input type="text" value="*99***1#"/>
SIM/UIM PIN:	<input type="text"/>
Access Point Name:	<input type="text" value="cmnet"/>
<b>GPRS Configuration:</b>	
PPP Username:	<input type="text"/>
PPP Password:	<input type="password"/>
Work Mode:	<input type="text" value="Disable"/> ▼
Max Redial Times:	<input type="text" value="5"/>
Redial Interval:	<input type="text" value="5"/>
Idle Time:	<input type="text" value="600"/>
COM:	<input type="text" value="COM1"/> ▼
<b>GPRS Status:</b>	
Link Status:	Disconnected
GPRS IP:	0.0.0.0
GPRS Gateway:	0.0.0.0
GPRS DNS1:	0.0.0.0
GPRS DNS2:	0.0.0.0
<input type="button" value="Submit"/> <input type="button" value="help"/>	

Figure 4-5 HTTP GPRS settings page


There is three parts in this page for configuration: MSC settings, GPRS configuration and GPRS status. Please refer to the description of the parameters in section 3.5.1, 3.5.2, 3.5.3.

## 4.6 Server Settings

In the main menu click on link “Server”, server configuration page will show as follows:

## Server Settings

---



Server Configurations

ARP cache Timeout:  (secs)

CPU Performance: ☐ High ☒ Regular

HTTP Server Port:

MTU Size:

Figure 4-6 HTTP server settings page

There is only one part in this page for configuration: server configuration. Please refer to the description of the parameters in section 3.6.

---



Note:

If value of HTTP Server Port is other than 80, please attach port number when access WEB in address format `http://address:port`.

---

## 4.7 Serial Channel

The NEPORT series, each serial port on behalf of a channel, includes 3 parts to be configured: serial port settings, connection settings, remote host configuration.

### 4.7.1 Hostlist

In the main menu click on link “Hostlist”, hostlist configuration page will show as follows:

## Hostlist Settings

---

### Channel 1

Retry Settings					
Retry Counter:		<input type="text" value="2"/>	Retry Timeout:		<input type="text" value="2"/>

Host Information					
No.	Host Address	Port	No.	Host Address	Port
1	<input type="text"/>	<input type="text" value="0"/>	2	<input type="text"/>	<input type="text" value="0"/>
3	<input type="text"/>	<input type="text" value="0"/>	4	<input type="text"/>	<input type="text" value="0"/>
5	<input type="text"/>	<input type="text" value="0"/>	6	<input type="text"/>	<input type="text" value="0"/>
7	<input type="text"/>	<input type="text" value="0"/>	8	<input type="text"/>	<input type="text" value="0"/>
9	<input type="text"/>	<input type="text" value="0"/>	10	<input type="text"/>	<input type="text" value="0"/>
11	<input type="text"/>	<input type="text" value="0"/>	12	<input type="text"/>	<input type="text" value="0"/>

Backup Link: ☒ Disable ☐ Enable

Figure 4-7 HTTP host list settings page

There is two parts in this page for configuration: Retry settings and Host information. Please refer to the description of the parameters in section 3.7.1, 3.7.2.



Note:

Host lists are valid only when in TCP client mode.

### 4.7.2 Serial Settings

In the main menu click on link “Serial setting”, serial port configuration page will show as follows:

## Serial Settings

---

### Channel 1

☒ Enable Serial Port

Port Settings

Protocol:	RS232	FIFO:	8
Flow Control:	None	Baud Rate:	9600
Data Bits:	8	Parity:	None
Stop bits:	1		

Pack Control

☐ Enable Packing

Idle Gap Time:	12	Match 2 Bytes Sequence:	<input type="radio"/> Yes <input checked="" type="radio"/> No
Send Frame Only:	<input type="radio"/> Yes <input checked="" type="radio"/> No	Match Byte:	0x00 0x00 (Hex)

Figure 4-8 HTTP serial settings page

There is two parts in this page for configuration: Port settings and Pack Control. Please refer to the description of the parameters in section 3.8.1, 3.8.2, 3.8.3.

## 4.7.3 Connection

### 4.7.3.1 Connection Protocol

Click on the drop list of Connection Protocol, you will see the two choice: TCP and UDP. There is different page for you when select different item.

### 4.7.3.2 UDP

Select UDP as connection protocol, the UDP page will show as follow:

## Connection Settings

---

### Channel 1

Connection Protocol: UDP ▼

Datagram Mode:

Datagram Type: Uni ▼ Accept Incoming: No ▼

Endpoint Configuration:

Local Port: 0 Remote Port: 0

Net Segment: 0.0.0.0

Device Address Table:

No.	Device Address	Device Address	Port
0	0.0.0.0	0.0.0.0	0
1	0.0.0.0	0.0.0.0	0
2	0.0.0.0	0.0.0.0	0
3	0.0.0.0	0.0.0.0	0

Local Port: 0

Submit

help

Figure 4-9 HTTP UDP settings page

There is three parts in this page for configuration: Datagram Mode, Endpoint configuration and Device Address Table. Please refer to the description of the parameters in section 3.9.2.

### 4.7.3.3 TCP

Select TCP as connection protocol, the TCP page will show as follow:

## Connection Settings

---

### Channel 1

Connection Protocol:

**Connect Mode**

Worked As:

Active Connect:  Start Character:

**Endpoint Configuration:**

Local Port:  Remote Port:

Remote Host:  Connect Response:

Use Hostlist: ☐ Yes ☒ No DNS Query Period:

**Disconnect Mode**

☐ On DSR Drop ☐ Hard disconnect ☐ Check EOT(Ctr-D)

Inactivity Timeout:  (Secs)

**Flush Mode**

Flush Input Buffer	Flush Output Buffer
<input type="checkbox"/> With Active Connect	<input type="checkbox"/> With Active Connect
<input type="checkbox"/> With Passive Connect	<input type="checkbox"/> With Passive Connect
<input type="checkbox"/> At Time of Disconnect	<input type="checkbox"/> At Time of Disconnect

Figure 4-10 HTTP TCP settings page

There is four parts in this page for configuration: Connect Mode, Endpoint configuration, Disconnect Mode and Flush Mode. Please refer to the description of the parameters in section 3.9.3.

## 4.8 Email Settings

In the main menu click on link “Email settings”, email configuration page will show as follows:

## Email Settings

---

**Configure Server**

SMTP Server:

SMTP Port:

Email Address:

Username:

☒ Change Password

Password:

**Recipients**

Recipient 1 Email:

Recipient 2 Email:

Recipient 3 Email:

Figure 4-11 HTTP email settings page

There is two parts in this page for configuration: Configure Server and Recipients. Please refer to the description of the parameters in section 3.10.

## 4.9 Trigger Settings

In the main menu click on link “trigger settings” under Email, trigger settings page will show as follows:

## Email Settings

---

Conditions	
Cold start:	Mail Off <input type="button" value="v"/>
Login auth failure:	Mail Off <input type="button" value="v"/>
Warm start:	Mail Off <input type="button" value="v"/>
IP changed:	Mail Off <input type="button" value="v"/>
DCD Changed:	Mail Off <input type="button" value="v"/>
Password changed:	Mail Off <input type="button" value="v"/>
DSR Changed:	Mail Off <input type="button" value="v"/>

Message Properties	
Subject:	<input type="text"/>
Priority:	Normal <input type="button" value="v"/>
Min.Notification Interval:	<input type="text" value="0"/> (secs)
<input type="button" value="Submit"/>	<input type="button" value="help"/>

Figure 4-12 HTTP email trigger settings page

There is two parts in this page for configuration: Conditions and Message Properties. Please refer to the description of the parameters in section3.11.

## 4.10 Input Trigger Settings

In the main menu click on link “Input trigger settings” under Email, input trigger settings page will show as follows:

### Input Trigger Settings

---

Conditions	
<b>Serial Trigger</b>	
<input type="checkbox"/> Enable Serial Input Trigger	
Channel:	Channel 2 <input type="button" value="v"/>
Data Size:	2 Bytes <input type="button" value="v"/>
Match Data:	0x00 <input type="text"/> 0x00 <input type="text"/>

Message Properties	
Subject:	<input type="text"/>
Priority:	Normal <input type="button" value="v"/>
Min.Notification Interval:	<input type="text" value="5"/> (secs)
Re-Notification Interval:	<input type="text" value="1"/> (secs)
<input type="button" value="Submit"/>	<input type="button" value="help"/>

Figure 4-13 HTTP email input trigger settings page

There is two parts in this page for configuration: Conditions and Message Properties. Please refer to the description of the parameters in section3.12.




## 4.11 SNMP Settings

In the main menu click on link “SNMP”, SNMP configuration page will show as follows:

### SNMP Settings

---



The image shows a web form titled "Settings" for SNMP configuration. It includes a checkbox for "Disable SNMP", and text input fields for "Read Community" (public), "Write Community" (private), "Contact Name" (Conextop), "Location", and "Notification Host" (0.0.0.0). At the bottom are "Submit" and "help" buttons.

<b>Settings</b>	
<input type="checkbox"/> Disable SNMP	
Read Community:	<input type="text" value="public"/>
Write Community:	<input type="text" value="private"/>
Contact Name:	<input type="text" value="Conextop"/>
Location:	<input type="text"/>
Notification Host:	<input type="text" value="0.0.0.0"/>
<input type="button" value="Submit"/>	<input type="button" value="help"/>

Figure 4-14 HTTP SNMP settings page


There is only one part in this page for configuration: SNMP settings. Please refer to the description of the parameters in section 3.13.

## 4.12 Password Setting

In the main menu click on link “Password settings”, password configuration page will show as follows:

### Password Settings

---



The image shows a web form titled "Change Password". It includes text input fields for "Username" (admin), "Old Password", "New Password", and "Retype Password". At the bottom are "Submit" and "help" buttons.

<b>Change Password</b>	
Username:	<input type="text" value="admin"/>
Old Password:	<input type="password"/>
New Password:	<input type="password"/>
Retype Password:	<input type="password"/>
<input type="button" value="Submit"/>	<input type="button" value="help"/>

Figure 4-15 HTTP password settings page

There is only one part in this page for configuration: change password. Please refer to the description of the parameters in section 3.14.



Note:

You can only modify the password of current user on this view.

---

## 4.13 Power manage

In the main menu click on link “Power manage”, system reset configuration page will show as follows:

### Power manage

---

New configurations will NOT take effect until rebooted.

**Warning! Both serial and ethernet connections will be dropped and data may be lost while rebooting.**

☐ Load defaults  
☐ Load defaults and reboot  
☐ Reboot  
☐ Save and reboot

Figure 4-16 HTTP power manage page

There is only one part in this page for configuration: power manage. Please refer to the description of the parameters in section3.15.

---



Caution:

Before system restarting, please check whether there is any parameters need to save, if so please select “Save and reboot” option, otherwise the configuration will not saved.

---

## 4.14 Logout

Click “Logout” in the menu bar, enter the “log out” page, the page will be shut down after 3 seconds, the user needs to re-verify when login again, as follows:

**Log out successfully!web will be closed in 2 seconds.**

Figure 4-17 HTTP logout page

## Chapter 5 TELNET Configuration

Telnet (teletype network) is a network protocol used on the Internet or local area networks to provide a bidirectional interactive communications facility. Typically, telnet provides access to a command-line interface on a remote host via a virtual terminal connection which consists of an 8-bit byte oriented data connection over the Transmission Control Protocol (TCP). User data is interspersed in-band with TELNET control information.

### 5.1 Basic Settings

Change to the main menu view, enter the shortcut keys before “basic settings”, then changed to the basic settings view, as follows:

```
-----
<<Main menu->Basic Setting>>
<1> Server name[]
<2> Time Zone[<GMT+08:00>Beijing, Chongqing, Hong Kong, Urumchi]
<3> Local Time[2008-08-08 21:58:55]
<4> Timer server[ntp0.pipex.net]
<5> Web Console[Enable]
<6> Telnet Console[Enable]
<M> Back to main menu
<Q> Quit

key in your selection:
```

Figure 5-1 TELNET basic settings view

Please refer to the description of the parameters in section 3.1.

### 5.2 Network

Change to the main menu view, enter the shortcut keys before “Network”, then changed to the network settings view, as follows:

```
-----
<<Main menu->Network settings>>
<1> Use static IP address[*]
<2> Obtain IP automatically
<3> speed/duplex[auto negotiate]
<4> Modify Mac Address[aa.bb.cc.dd.01.22]
<5> Network Type
<M> Back to main menu
<Q> Quit

key in your selection:
```

Figure 5-2 TELNET network settings view

### 5.2.1 Static IP address configuration

Change to the network setting view, enter the shortcut keys before “Use static IP address”, then changed to the static IP address settings view, as follows:

```
-----
<<Main menu->Network settings->Use static IP address>>
<1> Ip address[192.168.0.122]
<2> Subnet mask[255.255.255.0]
<3> Default gateway[192.168.0.3]
<4> Preferred DNS Server[192.168.0.3]
<5> Alternate DNS Server[0.0.0.0]
<M> Back to main menu
<Q> Quit

key in your selection:
```

Figure 5-3 TELNET static IP address view

Please refer to the description of the parameters in section 3.2.

### 5.2.2 Dynamic IP address configuration

Change to the network setting view, enter the shortcut keys before “Obtain IP automatically”, then changed to the dynamic IP address settings view, as follows:

```
-----
<<Main menu->Network settings->Obtain IP automatically>>
<1> BOOTP[Enable]
<2> DHCP[Enable]
<3> AutoIP[Enable]
<4> DHCP Host Name[]
<M> Back to main menu
<Q> Quit

key in your selection: _
```

Figure 5-4 TELNET dynamic IP address view

Please refer to the description of the parameters in section 3.2.

### 5.2.3 Netcard setting

Change to the network setting view, enter the shortcut keys before “Speed/duplex”, then changed to the netcard settings view, as follows:

```
-----
<<Main menu->Network settings->speed/duplex>>
<1> auto negotiate[*]
<2> User set
<M> Back to main menu
<Q> Quit

key in your selection: _
```

Figure 5-5 TELNET netcard settings view

Please refer to the description of the parameters in section3.2.

### 5.2.4 Network type

Change to the network setting view, enter the shortcut keys before “Network Type”, then changed to the network type settings view, as follows:

```
<<Main menu->Network settings->Network Type>>
<1> Ethernet[Enable]
<2> PPP[Disable]
<3> PPPoE[Disable]
<4> GPRS[Disable]
<M> Back to main menu
<Q> Quit

key in your selection:
```

Figure 5-6 TELNET network type view

Please refer to the description of the parameters in section3.2

## 5.3 PPPoE

Change to the main menu view, enter the shortcut keys before “PPPoE Settings”, then changed to the PPPoE settings view, as follows:

```
<<Main menu->PPPoE Settings>>
<1> User Name[admin]
<2> Password[*****]
<3> WorkMode[Disable]
<4> Max Redial Times[5]
<5> Redial Interval[5]
<6> Idle Time[600]
    Current Status[deactive]
    PPPoE IP[0.0.0.0]
    PPPoE Gateway[0.0.0.0]
    PPPoE DNS1[0.0.0.0]
    PPPoE DNS2[0.0.0.0]
<M> Back to main menu
<Q> Quit

key in your selection: _
```

Figure 5-7 TELNET PPPoE view

Please refer to the description of the parameters in section 3.3.

## 5.4 PPP

Change to the main menu view, enter the shortcut keys before “PPP Settings”, then changed to the PPP settings view, as follows:

```
<<Main menu->PPP Settings>>
<1> User Name[admin]
<2> Password[*****]
<3> WorkMode[Disable]
<4> Max Redial Times[5]
<5> Redial Interval[5]
<6> Idle Time[600]
<7> PPP Com ID[COM1]
    Current Status[deactive]
    PPP IP[0.0.0.0]
    PPP Gateway[0.0.0.0]
    PPP DNS1[0.0.0.0]
    PPP DNS2[0.0.0.0]
<M> Back to main menu
<Q> Quit

key in your selection:
```

Figure 5-8 TELNET PPP view

Please refer to the description of the parameters in section 3.4.

## 5.5 GPRS

Change to the main menu view, enter the shortcut keys before “GPRS Settings”, then

changed to the GPRS settings view, as follows:

```
<<Main menu->GPRS Settings>>
<1> Service Code[*99***1#]
<2> SIM/UIM PIN[]
<3> Access Point Name[cmnet]
<4> PPP Username[]
<5> PPP Password[]
<6> WorkMode[Disable]
<7> Max Redial Times[5]
<8> Redial Interval[5]
<9> Idle Time[600]
<a> GPRS Com ID[COM1]
    Current Status[deactive]
    GPRS IP[0.0.0.0]
    GPRS Gateway[0.0.0.0]
    GPRS DNS1[0.0.0.0]
    GPRS DNS2[0.0.0.0]
<M> Back to main menu
<Q> Quit

key in your selection:
```

Figure 5-9 TELNET GPRS view

Please refer to the description of the parameters in section 3.5.

## 5.6 Server Settings

Change to the main menu view, enter the shortcut keys before “Server Settings”, then changed to the Server settings view, as follows:

```
<<Main menu->Server Settings>>
<1> ARP Cache Timeout[255]
<2> CPU Performance Mode[REGULAR]
<3> HTTP Server Port[80]
    MTU Size[1024]
<M> Back to main menu
<Q> Quit

key in your selection: _
```

Figure 5-10 TELNET server settings view

Please refer to the description of the parameters in section 3.6.

## 5.7 Channel settings

Change to the main menu view, enter the shortcut keys before “Serial Channel”, then changed to the serial channel view, as follows:

```

<<Main menu->Serial Channel>>
<1> Serial Channel1
<2> Serial Channel2
<M> Back to main menu
<Q> Quit

key in your selection:

```

Figure 5-11 TELNET serial channel view

Change to the serial channel view, enter the shortcut keys before “Serial Channelx”(x is the channel No.), then changed to the specified serial channel view, as follows:

```

<<Main menu->Serial Channel->Serial Channel1>>
<1> Connection Settings[TCP]
<2> Hostlist settings
<3> Serial settings
<M> Back to main menu
<Q> Quit

key in your selection:

```

Figure 5-12 TELNET specified serial channel view

### 5.7.1 Hostlist

Change to the specified serial channel view, enter the shortcut keys before “Hostlist settings”, then changed to the hostlist settings view, as follows:

```

<<Main menu->Serial Channel->Serial Channel1->Hostlist settings>>
<1> Retry Counter[2]
<2> Retry Timeout[2]
<3> Host1
<4> Host2
<5> Host3
<6> Host4
<7> Host5
<8> Host6
<9> Host7
<a> Host8
<b> Host9
<c> Host10
<d> Host11
<e> Host12
<f> backup link[Disable]
<M> Back to main menu
<Q> Quit

key in your selection:

```

Figure 5-13 TELNET hostlist settings view

Please refer to the description of the parameters in section .



### 5.7.2 Serial Settings

Change to the specified serial channel view, enter the shortcut keys before “Serial settings”, then changed to the Serial settings view, as follows:

```
<<Main menu->Serial Channel->Serial Channel1->Serial settings>>
<1> Enable Serial Port[Enable]
<2> Protocol[RS232]
<3> Baud rate[9600]
<4> Data bits[8]
<5> Stop bits[1]
<6> Parity[N0]
<7> Flow control[None]
<8> FIFO[8]
<9> Enable Packing[No]
<M> Back to main menu
<Q> Quit

key in your selection:
```

Figure 5-14 TELNET serial settings view

Please refer to the description of the parameters in section 3.8.

### 5.7.3 Connection

#### 5.7.3.1 Connection Protocol

Change to the specified serial channel view, enter the shortcut keys before “Connection settings”, then changed to the Connection protocol view, as follows:

```
<<Main menu->Serial Channel->Serial Channel1->Connection Settings
>>
<1> TCP
<2> UDP[*]
<M> Back to main menu
<Q> Quit

key in your selection:_
```

Figure 5-15 TELNET connection protocol view

#### 5.7.3.2 UDP

Change to the connection protocol view, enter the shortcut keys before “UDP”, then changed to the UDP view, as follows:

```
<<Main menu->Serial Channel->Serial Channel1->Connection Settings
->UDP>>
<1> Accept incoming[No]
<2> Datagram type[Unil
<M> Back to main menu
<Q> Quit

key in your selection:
```

Figure 5-16 TELNET UDP view

Please refer to the description of the parameters in section 3.9.2.

### 5.7.3.3 TCP

Change to the connection protocol view, enter the shortcut keys before “TCP”, then changed to the TCP view, as follows:

```
<<Main menu->Serial Channel->Serial Channel1->Connection Settings
->TCP>>
<1> Work As[Server]
<2> Active connect[None]
<3> Start character[0x0]
<4> Local port[27001]
<5> Remote port[0]
<6> Remote host[]
<7> Connect Response[None]
<8> Use Hostlist[Disable]
<9> DNS Query Period[1800]
<a> Disconnect Mode
<b> Flush input buffer
<c> Flush output buffer
<M> Back to main menu
<Q> Quit

key in your selection:
```

Figure 5-17 TELNET TCP view

Please refer to the description of the parameters in section 3.9.3.

## 5.8 Email Settings

Change to the main menu view, enter the shortcut keys before “Email Settings”, then changed to the Email view, as follows:

```
<<Main menu->Email settings>>
<1> Email Settings
<2> Trigger Settings
<3> Input Trigger Settings
<M> Back to main menu
<Q> Quit

key in your selection:
```

Figure 5-18 TELNET email view

### 5.8.1 Email Settings

Change to the email view, enter the shortcut keys before “Email Settings”, then changed to the Email settings view, as follows:

```
<<Main menu->Email settings->Email Settings>>
<1> SMTP Server[test.smtp.srv]
<2> SMTP Port[25]
<3> Email Address[]
<4> User name[]
<5> Password[*****]
<6> Recipient 1 Email[]
<7> Recipient 2 Email[]
<8> Recipient 3 Email[]
<M> Back to main menu
<Q> Quit

key in your selection:
```

Figure 5-19 TELNET email settings view

Please refer to the description of the parameters in section 3.10.

### 5.8.2 Trigger Settings

Change to the email view, enter the shortcut keys before “Trigger Settings”, then changed to the normal email trigger view, as follows:

```
<<Main menu->Email settings->Trigger Settings>>
<1> Cold start[Disable]
<2> Warm start[Disable]
<3> Login auth failure[Disable]
<4> IP changed[Disable]
<5> Password changed[Disable]
<6> DCD changed[Disable]
<7> DSR changed[Disable]
<8> Subject[]
<9> Priority[NORMAL]
<a> Min.Notification Interval<Secs>[0]
<M> Back to main menu
<Q> Quit
```

key in your selection:

Figure 5-20 TELNET normal email trigger view

Please refer to the description of the parameters in section 3.11.

### 5.8.3 Input Trigger Settings

Change to the email view, enter the shortcut keys before “Input Trigger Settings”, then changed to the input email trigger view, as follows:

```
<<Main menu->Email settings->Input Trigger Settings>>
<1> Enable Serial Trigger Input[Disable]
<2> Subject[]
<3> Priority[NORMAL]
<4> Min.Notification Interval<Secs>[5]
<5> Re-Notification Interval<Secs>[1]
<M> Back to main menu
<Q> Quit
```

key in your selection: \_

Figure 5-21 TELNET input email trigger view

Please refer to the description of the parameters in section 3.12.

## 5.9 SNMP Settings

Change to the main menu view, enter the shortcut keys before “SNMP Settings”, then changed to the SNMP view, as follows:

```
<<Main menu->SNMP Setting>>
<1> Disable SNMP[No]
<2> Read Community[public]
<3> Write Community[private]
<4> Contact Name[]
<5> Location[ShenZhen]
<6> Notification Host[0.0.0.0]
<M> Back to main menu
<Q> Quit

key in your selection: _
```

Figure 5-22 TELNET SNMP view

Please refer to the description of the parameters in section 3.13.

## 5.10 User Manage

Change to the main menu view, enter the shortcut keys before “User manage”, then changed to the user manage view, as follows:

```
<<Main menu->User Manage>>
<1> User1
<2> User2
<3> User3
<4> User4
<5> User5
<M> Back to main menu
<Q> Quit

key in your selection: _
```

Figure 5-23 TELNET user manage view

There is 5 users for configuration, the first user admin has the administrator privilege and can not be deleted. The others are normal user can be modified and deleted by admin.

Change to the user manage view, enter the shortcut keys before “User1”, and then changed to the administrator view, as follows:

```
<<Main menu->User Manage->User1>>
<1> Change password[*****]
<M> Back to main menu
<Q> Quit

key in your selection: _
```

Figure 5-24 TELNET administrator view

Change to the user manage view, enter the shortcut keys before “Userx”(2-5), then changed to the user view, as follows:

```
<<Main menu->User Manage->User2>>
<1> Change user name[2]
<2> Change password[*****]
<3> Delete user
<M> Back to main menu
<Q> Quit

key in your selection: _
```

Figure 5-25 TELNET normal user view

**Caution:**

The user manage view only appear when admin login.

## 5.11 Password Setting

Change to the main menu view, enter the shortcut keys before “Password Setting”, then changed to the password settings view, as follows:

```
<<Main menu->Change password>>
<1> Change password[*****]
<M> Back to main menu
<Q> Quit

key in your selection:
```

Figure 5-26 TELNET password settings view

## 5.12 Load factory default

Change to the main menu view, enter the shortcut keys before “Load factory default”, then changed to the load factory view, as follows:

```
<c> Load factory default
<d> Save and Reboot
<e> View Settings
<Q> Quit

key in your selection:cAre you sure?(y/n):
```

Figure 5-27 TELNET load factory view

## 5.13 Save and Reboot

Change to the main menu view, enter the shortcut keys before “Save and Reboot”, then

changed to the save and reboot view, as follows:

```
<c> Load factory default
<d> Save and Reboot
<e> View Settings
<q> Quit

key in your selection:dAre you sure?(y/n):
```

Figure 5-28 TELNET save and reboot view

## 5.14 View Settings

Change to the main menu view, enter the shortcut keys before “View Settings”, then you can view all the settings page by page, press any key to view next page.

```
<<Main menu->Basic Setting>>
  Server name[]
  Time Zone[<GMT+08:00>Beijing, Chongqing, Hong Kong, Urumchi]
  Local Time[2008-08-09 21:49:43]
  Timer server[ntp0.pipex.net]
  Web Console[Enable]
  Telnet Console[Enable]

Press any key to continue..._
```

Figure 5-29 view the settings

# Chapter 6 AT Command

AT command is a set of communication protocols between a host computer and devices. AT originated in the word "Attention", it was first used for communication between terminal and modem, and then latter gradually evolved into industry standards for communications equipment. NEPORT series products expands it, support the use of AT commands to configure device parameters and network connectivity and so on.

## 6.1 AT commands for parameters setting

Please refer to the CONEXTOP NEPORT AT commands to get the detail description of AT commands.

### 6.1.1 Basic Settings

command	contents
AT!BC	WEB and TELENT console switch
AT!BDN	Set the name of device
AT!BTS	Set time related parameters.

Table 6-1 AT commands for basic settings

### 6.1.2 Network

command	contents
AT!EC	Ethernet settings
AT!IC	IP address obtain methods settings
AT!AIC	Automatically obtain IP address settings

Table 6-2 AT commands for network

### 6.1.3 PPPoE

command	contents
AT!PC	PPPoE dial-up settings
AT!PS	PPPoE status query

Table 6-3 AT commands for PPPoE



### 6.1.4 PPP

command	contents
AT!PSC	PPP dial-up settings
AT!PSS	query PPP status

Table 6-4 AT commands for PPP

### 6.1.5 GPRS

command	contents
AT!PGC	GPRS dial-up settings
AT!PGS	GPRS status
AT!SUP	SIM/UIM card PIN
AT!WMSC	Mobile service center settings

Table 6-5 AT commands for GPRS

### 6.1.6 Server Settings

command	contents
AT!HP	Set HTTP server port
AT!SC	Server settings

Table 6-6 AT command for server settings

### 6.1.7 Host list

command	contents
AT!HC	Host lists retry settings
AT!HHL	Host lists host settings

Table 6-7 AT commands for host list

### 6.1.8 Serial Settings

command	contents
AT!SP	Whether or not to enable serial port
AT!SPP	Serial port properties
AT!SPPC	Serial port packing settings

Table 6-8 AT commands for serial settings

### 6.1.9 Connection

command	contents
AT!CPC	Connection protocol
AT!CTCR	TCP connection response
AT!CTDM	TCP hard disconnect
AT!CTFIB	Clear input buffer settings
AT!CTFOB	Clear output buffer settings
AT!CTIT	TCP connection idle time
AT!CTUHL	Whether or not enable hostlist function
AT!TC	TCP configuration
AT!UDM	UDP datagram type
AT!UDT	UDP uni-cast address table
AT!UMC	UDP multi-cast settings

Table 6-9 AT commands for connection

### 6.1.10 Email Settings

command	contents
AT!REC	Email receipt settings
AT!SEC	Email sender settings
AT!SMTPC	SMTP server settings

Table 6-10 AT commands for email settings

### 6.1.11 Trigger Settings

command	contents
AT!ET	Normal email trigger settings
AT!ETEC	Normal email properties

Table 6-11 AT commands for trigger settings

### 6.1.12 Input Trigger Settings

command	contents
AT!EITC	Input trigger mail settings
AT!EITEC	Mail properties triggered by serial input data

Table 6-12 AT commands for input trigger settings

### 6.1.13 SNMP

command	Contents

Table 6-13 AT commands for SNMP

### 6.1.14 Password Setting

command	contents
AT!UM	Use manage

Table 6-14 AT commands for password setting

### 6.1.15 Special command

command	contents
AT!V	Show all the AT command
AT!EXIT	Quit AT command mode
AT!LD	Load factory value
AT!R	Save and reset device
AT!S	Save the parameters
AT!SL	Enter the serial login mode

Table 6-15 special AT command

## 6.2 FTP AT command

NEPORT series supports the use of AT commands for the operation of FTP client, provides traditional industries devices with the FTP client function. Users only need to send AT commands through the serial port, and then can achieve a two-way file transmission between storage systems of the NEPORT series products, FTP servers and local.




Figure 6-1 using AT command for FTP Scenarios

### 6.2.1 Local and device

command	contents
AT!LFOP	Open a file in device
AT!LFCL	Close a file in device opened
AT!LFRD	Read data from device file
AT!LFWR	Write data to device file
AT!LFLS	List all the files in device

Table 6-16 AT commands for local and device

### 6.2.2 Local and FTP server

command	contents
AT!RCOP	Open a ftp connection and login from local
AT!RCCL	Close a ftp connection from local
AT!RFOP	Open a file on FTP server from local
AT!RFCL	Close a file on FTP server from local
AT!RFRD	Read data from file on FTP server from local
AT!RFWR	Write data to file on FTP server from local
AT!RFLS	List all the files on FTP server from local

Table 6-17 AT commands for local and FTP server

### 6.2.3 Device and FTP server

command	contents
AT!RCOP	Open a ftp connection and login from device
AT!RCCL	Close a ftp connection from device
AT!RFPUT	Write data to file on FTP server from device
AT!RFGET	Read data from file on FTP server from device

Table 6-18 AT commands for device and FTP server

### 6.2.4 Read file procedure

Whether to read file data from the device to the local, or read the file from the FTP server data to local, in addition to differences in the command format, the same process has been followed. First of all, to open the file, and then read from a data file, in order to distinguish between the data blocks, the read file data command must carry the serial number of data blocks, if failed to read, the same piece of data can be read again, prevent the loss of data blocks; close the file when finish, otherwise an error will occur when read and write documents again.




Figure 6-2 using AT command to read data from file

### 6.2.5 Write to file procedure

The same as reading data from file, whether to write file data to the device, or write the file to FTP server, in addition to differences in the command format, the same process has been followed. First of all, to open the file, and then write data to file, in order to distinguish between the data blocks, the write file data command must carry the serial number of data blocks, if failed to write, the same piece of data can be send again, prevent the loss of data blocks; close the file when finish, otherwise an error will occur when read and write documents again.




Figure 6-3 using AT command to write to file

## Chapter 7 DeviceManagement

NEPORT series product's DeviceManagement is an excellent device server management tool on PC. You can search and configure the remote NEPORT serial device servers easily. With this utility, you can:

- Search all the devices on the local network.
- Configure and view devices' settings.
- Perform diagnostic tests (with Ping, IE, Telnet).

This management utility window is divided into 4 parts (show in 2.2.2.4):

The main menu contains the function list and information of this utility.

The shortcuts field of function is just below the main menu, you can access the functions more convenient than from the main menu.

The devices list view is on the left part below shortcuts field, it shows brief information of devices, and you must select item from it to operate.

### 7.1 Functions

#### 7.1.1 Menu Items




图 7-1 main menu of Devicemanagement

### 7.1.1.1 Operate

Menu item	Description
Search	Search all the devices in the same LAN, add to list view when found a device.
Specify Search	Search for a specified device according to IP address.
Config	Query or set configuration of device.
Clear	Delete all items from the list view control.
Exit	Quit

Table 7-1 basic operation of Devicemanagement

### 7.1.1.2 Tools

Menu item	Description
IE	Start Internet Explorer to visit the WEB pages of a device selected from the list view.
Telnet	Use Telnet to log in device selected from the list view.
Ping	Ping the device selected from the list view.
Shortcut Key	Set the shortcut key of operations.

Table 7-2 tools of DeviceManagement

### 7.1.1.3 Language

Menu item	Description
English	Select English as the language of software interface.
Chinese-Simplified	Select Chinese-Simplified as the language of software interface.
Chinese-Traditional	Select Chinese-Traditional as the language of software interface.

Table 7-3 language of DeviceManagement

### 7.1.1.4 Help

Menu item	Description
About	About the software.
Update	Update software.

Table 7-4 Help menu of DeviceManagement



### 7.1.2 Shortcuts Field




Figure 7-2 shortcuts field of DeviceManagement

The shortcuts field is consist of Icons, every Icon stands for a shortcut of a menu item. You can simple click on the Icon instead of clicking on the menu item.

### 7.1.3 Devices List View




Figure 7-3 device list view of DeviceManagement

Every item in the list view stands for a device in the LAN. It shows the name, IP address, physical address of the device to distinguish each other.

When an item is selected, it will be highlighted. You can operate it by menu items, or by shortcuts, or click the right button of mouse then select from the context menu. The content of context menu is the same as the main menu. The details of the menu items is descript in section 7.1.1.



Caution:

The IP address and physical address are the features of devices, must different with others, if there is two devices have the same features, unknown problems will occur.

## 7.2 Configuring Devices

Except WEB and TELNET, you can use the Config function of this software to configure the device.

You can execute this function through main menu or context menu, or shortcut of Config, or shortcut key of Config, or just double click on the device item.

### 7.2.1 Login

Before you can configure the device, maybe you will be prompted to fill use name and password for login as follows:





图 7-4 login window of DeviceManagement

Fill in with correct user name and password, and then click the Login button to verify.

### 7.2.2 Configure


If verification is successful, the configuration page is show as follow.



### 7-5 configuration window of DeviceManagement

The content of configuration page is the same as the WEB page, except some different in layouts and buttons, in the left index column you can click the + to unfold the sub menus, click the – to fold the sub menus. The operation of configuration is also the same as the WEB pages, moreover, you can click the Refresh button to re-retrieve the configuration of device, click the Close button to exit from configuration.

## NePort Summary

Embedded Seial-IP series			NePort –L Series		NePort-R Series		NePort Series		NePort-EN Series		
Single port series			LX	LX	RX	RX	SX	SX	EXH	EXH	ESX
				-485		-485		-485		-485	
Memory and Speed	Flash		128k	128k	256k	256k	512k	512k	512k	512k	512k
	Code/Boot(KB)		/32	/32	/32	/32	/32	/32	/32	/32	/32
	SRAM(KB)		80/128	80/128	128	128	256	256	256	256	256
	Speed (MIPS)		55	55	55	55	55	55	60	60	60
Core and System	ARM7TDMI		Y	Y	Y	Y	Y	Y	Y	Y	Y
	Multi-T RTOS		Y	Y	Y	Y	Y	Y	Y	Y	Y
Serial Interfaces	Ethernet Speed (M)		10/100	10/100	10/100	10/100	10/100	10/100	10/100	10/100	10/100
	Uart	RS232	Y	Y	Y	Y	Y	Y	Y	Y	Y
		RS485/422		Y		Y		Y		Y	Y
	Max-Baudrate(bps)		115200	115200	460800	460800	460800	460800	921600	921600	921600
	Serial port Number		1	1	1	1	1	1	1/2/3	1/2/3	1/2/3
Programmable I/O	PIO Number		--	2	--	2	--	--	--	2	2
Protocol stacks	ARP/IP/ICMP/DHCP /BOOTP/TCP/UDP		Y	Y	Y	Y	Y	Y	Y	Y	Y
	TFTP		Y	Y	Y	Y	Y	Y	Y	Y	Y
	SNTP		--	--	--	--	Y	Y	--	Y	Y
	Http Server (web customized)			--Y	Y	Y	Y	Y	Y	Y	Y
	Telnet Server		Y(*)	Y(*)	Y	Y	Y	Y	Y	Y	Y
	DNS		Y(*)	Y(*)	Y(*)	Y(*)	Y	Y	Y	Y	Y
	Smtpt (Email Trigger)		--	--	--	--	Y(*)	Y(*)	--	Y	Y
	PPP/PPPOE		--	--	--	--	--	Y(*)	--	--	Y
Advanced encryption protocols	SSH		--	--	--	--	--	--	--	--	Y
	SSL/TLS		--	--	--	--	--	--	--	--	Y
	Https		--	--	--	--	--	--	--	--	Y
	Smtpts		--	--	--	--	--	--	--	--	Y
Encryption Arithmetic	AES		--	--	--	--	--	--	--	--	Y
	DES/Triple-DES		--	--	--	--	--	--	--	--	Y
	RC4		--	--	--	--	--	--	--	--	Y
	MD5		--	--	--	--	--	--	--	--	Y
Analog parameters	Power supplier(V)		3.3	3.3	3.3	3.3	3.3	3.3	3.3	3.3	3.3
	I/O Tolerant(V)		5	5	5	5	5	5	5	5	5
PowerConsumption (mA)	10Base-T Activity		165	165	165	165	165	165	165	165	165
	100Base-T Activity		155	155	155	155	155	155	155	155	155
Operating temperature arrange C = 0 - +75° C      I = - 40 - +85° C			C,I	C,I	C,I	C,I	C,I	C,I	C,I	C,I	C,I
Package Option  (RJ45)			RJ45 Low Cost	RJ45 Low Cost	RJ45	RJ45	RJ45	RJ45	RJ45	RJ45	RJ45

More details by: <http://www.conextop.com/products/embeddeddsolution/wiredmodules/index.htm>

For details contact your local Conextop representative or  
Conextop directly:

call OEM sales support at 86-755-26505615

More details about NePort at <http://www.conextop.com>

© Conextop Technologies –November 2003 - All rights reserved

The Conextop corporate logo is a registered trademark of Conextop Technology. All other names are the property of their respective owners.

©2003 Conextop, Inc. All rights reserved. Conextop, NePort, with its patent-pending technology, and neChip are trademarks of Conextop. All other trademarks are the property of their respective owners. Specifications subject to change without notice. All rights reserved.